


**DD/TX5b**




(01) 2000000179680( 94)


# TX5b









- PL** Instrukcja montażu
- DE** Montageanweisung
- GB** Installation instruction
- FR** Instructions de montage
- RU** Инструкция монтажа
- CZ** Návod k montáži
- RO** Instrucțiuni de montaj
- HU** Útmutató
- SK** Návod na montáž




# DD/TX5b





	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
DD/TX5b	2	6	6	4	4	8	8	6	6	1	1	4	2+2	2	1+1



























# DD/TX5b







- C2119 (70)
- C2120 (80)
- C2121 (90)
- C2122 (100)



- S0962 (70)
- S0963 (80)
- S0964 (90)
- S0965 (100)



- C2126 (70)
- C2128 (80)
- C2130 (90)
- C2132 (100)



- C2125 (70)
- C2127 (80)
- C2129 (90)
- C2131 (100)

